


Contactors Accessories


AUXILIARY CONTACTS



Frame Sizes 22AF - 150AF

Part No.	Poles	Configuration	Mounting	Contact Arrangement
----------	-------	---------------	----------	---------------------


UA-1-11	2	1NO/1NC	Side	
---------	---	---------	------	--



UA-2-20	2	2NO	Front	
---------	---	-----	-------	--

UA-2-11	2	1NO/1NC	Front	
---------	---	---------	-------	--

UA-2-02	2	2NC	Front	
---------	---	-----	-------	--




UA-4-40	4	4NO	Front	
---------	---	-----	-------	--

UA-4-31	4	3NO/1NC	Front	
---------	---	---------	-------	--

UA-4-22	4	2NO/2NC	Front	
---------	---	---------	-------	--

UA-4-13	4	1NO/3NC	Front	
---------	---	---------	-------	--


UA-4-04	4	4NC	Front	
---------	---	-----	-------	--




Frame Sizes 225AF - 800AF

Part No.	Poles	Configuration	Mounting	Contact Arrangement
----------	-------	---------------	----------	---------------------


AU-100-11	2	1NO/ 1NC	Side	
-----------	---	----------	------	--



Installation Instructions



To install side mounting unit remove the indicated part in the circle in the fig. first. And then fit each part as shown. To separate push forward and pull.



To install front mounting unit fit it on the upper part of the front of the contactor and push it down. To separate pull the lever of the unit and push the unit upward.